



UNITED

LABORATORIES

**NO ACIDS...NO CAUSTICS...
NO EMULSIFIERS!
WILL REDUCE BOD, COD,
FOG AND SS LEVELS.**

LIFT STATIONS:

Use **United 384** with an A856 metering pump to achieve around-the-clock feed. This feed system offers 15-minute interval settings up to ninety-six settings in one 24-hour period. Each time the pump is activated, 3.3 oz. (100 mL) of material are dispensed.

Dose rate on **United 384** will depend on the size of the station to be treated and the flow rate through the station.

When **United 384** is fed to a lift station with a grease cap, care must be taken to note the thickness of the grease cap before treating with **United 384**. The product works from the bottom of the grease to the top. Check the thickness of the grease cap one week after initial dose to assess the performance of the product.

MAINS:

Use **United 384** with the A856 pump system mentioned under the Lift Station application. **United 384** is particularly appropriate for main application as the pump allows application of the product at low flow periods, day or night.

Dose rate depends on the size of the main and the flow rate. Your United Representative has a chart for your convenience.

United 384

PRE-TREAT Stabilized Liquid Bacteria And Enzyme Concentrate In A Spore State

**KEEP OUT OF REACH OF CHILDREN.
See other cautions on back/side panel**

PRECAUCION AL USARIO:

Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

**Manufactured and Sold Exclusively By:
UNITED LABORATORIES, INC.
320 37th Avenue • St. Charles, IL 60174
1-800-323-2594 • www.unitedlabsinc.com**

STORAGE AND HANDLING:

Store in a cool, dry place. Keep out of sunlight. Avoid exposure to extreme temperatures below 35°F (2°C) and above 130°F (54°C), disinfectants, or chlorine compounds such as bleach. Wash hands thoroughly after handling and avoid contact with eyes or open wounds.

FIRST AID MEASURES:

IF IN EYES: Flush with plenty of water for at least 15 minutes and call a physician or Poison Control center.

IF ON SKIN: Wash with soap and water. If irritation persists, call a physician or Poison Control Center.

IF INHALED: Remove to fresh air. If symptoms develop, seek medical attention. If not breathing, give artificial respiration.

IF SWALLOWED: Rinse mouth and throat. Give two glasses of water. Never give anything by mouth to an unconscious person. Do not induce vomiting. Call a physician or Poison Control Center.

An SDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the SDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

HMIS® III CODE: 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX: Glasses	HEALTH	0
	FLAMMABILITY	0
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	A